

Use only for OPV. BCG. Hib lyophilized, influenza seasonal (Ivophilized). JE lyophilized, measles, MR, MMR, meningococcal A. meningococcal **ACYW 135** (Ivophilized). rabies (lyophilized). rotavirus (Bharat liquid and lyophilized - other than RotaTeg®),

rubella, varicella, vellow fever

## **SENDER**

- 1. Prepare the shipping container.
- 2. Lift clear film on front of Indicator to retrieve twin bar code label, then
- stick the label to the shipping document.

  3. Activate the TIC20-WA/B by pressing and holding the START button ountil "MONITORING" finishes flashing (3 seconds), then release the
- button, with a start delay of 1 hour.

  4. Complete the card below in ball point pen.
- Insert this card, with the activated device attached, into the shipping container
- Seal the shipping container.

Vaccine:

Supplier name:					
Date:		Time:			
	dd.mm.yyyy		hh:mm		
Vaccine PC	) number:				

RECEIVER: please turn the card!



## RECEIVER

- On arrival, remove the TIC20-WA/B from the shipping container immediately.
   Press and hold the STOP button outil "STOPPED" finishes flashing
- (3 seconds), then release the button. The TIC20-WA/B is now stopped.
  3. Read the LCD display and follow the instructions as described below

## OK DISPLAY

recorded

Device is stopped.

OK shows that no alarms were

The trip length was 31 days and 15 hours.

If OK, use vaccines normally.



# ALARM DISPLAY Device is stopped.

shows an **ALARM** was recorded. In this example, the alarm occurred at a temperature >= 30 °C, indicated by the

arrow . on a day in Week 2.



If the TIC20-WA/B displays an alarm, please proceed according to the decision table below:

Alarm	What to do with vaccines:			
temperature	OPV only	other Vaccines		
>= 45 °C	Contact Procurement Agency	Contact Procurement Agency		
>= 30 °C	Contact Procurement Agency	Contact Procurement Agency		
>= 10 °C	Contact Procurement Agency	Accept		

Assembled and distributed by LogTag North America Inc. https://logtag.com Copyright 2022 LogTag North America. All rights reserved.